

10 cm REFERENCE LINE - measure between the end ticks; under 99.5 mm or over 100.5 mm means the printer is scaling

2 cm CALIBRATION SQUARE - measure before cutting



